# Bolt/flangemøtrik

Only one bolt model is required for mounting your X-Tray system.



One M8 carriage bolt with a square shoulder to save you having to hold against when you tighten the nut. The bags are stand-up and re-closable.

## Modeller

| | ARTIKLER / BESKRIVELSE | OVERFLADEBEHANDLING |
|---|---|---|
|  | **2761**<br>X61 Bolt M8x27 | Sort Zink |
|  | **2762**<br>X62 Flange Nut M8 | Sort Zink |
|  | **7100-031**<br>Expander Bolt M8x65 | Forzinket |
|  | **7100-070**<br>Self drilling screw, washer head 4.2x19 | Forzinket |