

Est 1990

## 0-180° fittings

Fitting at an angle of up to 180°. The fitting is used where the machine guard needs to be set up at angles other than 90°.



## Models

